

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BLX9
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> M20A-FXS (ENGINE CONTROL): SFI SYSTEM: P046673; EVAP System Vent Valve Stuck Closed Actuator Stuck Closed; 2023 - 2024 MY Prius Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P046673</b>	<b>EVAP System Vent Valve Stuck Closed Actuator Stuck Closed</b>
------------	----------------	--

## DTC SUMMARY

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	DTC OUTPUT FROM	PRIORITY	NOTE
P046673	EVAP System Vent Valve Stuck Closed Actuator Stuck Closed	Following condition is met during key-off EVAP monitor: <ul style="list-style-type: none"> <li>EVAP pressure change when vent valve on (closed) less than 0.3 kPa [0.04 psi]</li> </ul>	<ul style="list-style-type: none"> <li>Canister pump module (reference orifice, leak detection pump, vent valve)</li> <li>Connector/wire harness (Canister pump module - ECM)</li> <li>Canister (filter inside canister clogged)</li> <li>ECM</li> </ul>	Comes on	Engine	B	SAE Code: P2422

DTC NO.	MONITORING ITEM	DETECTION TIMING	DETECTION LOGIC	SAE CODE
P046673	Vent valve (built into canister pump module) stuck closed	EVAP monitoring (ignition switch off)	2 trip	P2422

### **HINT:**

The vent valve is built into the canister pump module.

## DESCRIPTION


Refer to EVAP (Evaporative Emission) System.


Click here [INFO](#)

## MONITOR DESCRIPTION

P046673: Vent valve stuck closed

In operation C, the vent valve turns on (closed) and the EVAP system pressure is then measured by the ECM using the canister pressure sensor to conduct an EVAP leak check. If the pressure does not increase when the vent valve is open, the ECM interprets this as the vent valve being stuck closed. In this case the ECM will illuminate the MIL and store this DTC.





## MONITOR STRATEGY

Required Sensors/Components (Main)	Canister pump module Purge VSV
Required Sensors/Components (Related)	-
Frequency of Operation	Once per driving cycle
Duration	Within 7 minutes
MIL Operation	2 driving cycles

Sequence of Operation

None

## TYPICAL ENABLING CONDITIONS

Key-off monitor runs when all of the following conditions are met	-
Atmospheric pressure	70 kPa(abs) [10.2 psi(abs)] or higher, and less than 110 kPa(abs) [16 psi(abs)]
Auxiliary battery voltage	10.5 V or higher
Vehicle speed	Less than 4 km/h (2.5 mph)
Ignition switch	Off
Engine condition	Not running
Key-OFF duration	5, 7 or 9.5 hours
Pressure sensor of canister pump module malfunction (P0451, P0452, P0453)	Not detected
Fuel tank pressure sensor malfunction (P1451, P1452, P1453)	Not detected
Purge VSV	Not operated by scan tool
Vent valve	Not operated by scan tool
Fuel vapor-containment valve	Not operated by scan tool
Leak detection pump	Not operated by scan tool
Purge flow before key-OFF	Performed
Engine coolant temperature	4.4°C (39.9°F) or higher, and less than 35°C (95°F)
Intake air temperature	4.4°C (39.9°F) or higher, and less than 35°C (95°F)

## TYPICAL MALFUNCTION THRESHOLDS

EVAP pressure change after EVAP canister vent valve on (closed)

Less than 0.3 kPa [0.04 psi]

## MONITOR RESULT

Refer to EVAP system.

Click here [INFO](#)

## CONFIRMATION DRIVING PATTERN

### NOTICE:

- The Evaporative System Check (Automatic Mode) consists of 9 steps performed automatically by the GTS. It takes a maximum of approximately 40 minutes.
- Do not perform the Evaporative System Check when the fuel tank is more than 90% full because the cut-off valve may be closed, making the fuel tank leak check unavailable.
- Do not start the engine during this operation.
- When the temperature of the fuel is 35°C (95°F) or higher, a large amount of vapor will form and any check result will be inaccurate. When performing the Evaporative System Check, keep the fuel temperature less than 35°C (95°F).

**HINT:**

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here [INFO](#)

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here [INFO](#)

1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
2. Turn the ignition switch off and wait for at least 30 seconds.
3. Turn the ignition switch to ON [A].
4. Enter the following menus: Powertrain / Engine / Utility / Evaporative System Check / Automatic Mode [B].
5. After the Evaporative System Check is completed, check for All Readiness by entering the following menus: Powertrain / Engine / Utility / All Readiness.
6. Input the DTC: P046673.
7. Check the DTC judgment result.

**HINT:**

- If the judgment result is NORMAL, the system is normal.
- If the judgment result is ABNORMAL, the system is malfunctioning.
- [A] to [B]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- When clearing the permanent DTCs, do not disconnect the cable from the auxiliary battery terminal or attempt to clear the DTCs during this procedure, as doing so will clear the universal trip and normal judgment histories.

**CAUTION / NOTICE / HINT****NOTICE:**

- Vehicle Control History may be stored in the hybrid vehicle control ECU if the engine is malfunctioning. Certain vehicle condition information is recorded when Vehicle Control History is stored. Reading the vehicle conditions recorded in both the freeze frame data and Vehicle Control History can be useful for troubleshooting.

for HEV Model: Click here [INFO](#)

for PHEV Model: Click here [INFO](#)

(Select Powertrain in Health Check and then check the time stamp data.)

- If any "Engine Malfunction" Vehicle Control History item has been stored in the hybrid vehicle control ECU, make sure to clear it. However, as all Vehicle Control History items are cleared simultaneously, if any Vehicle Control History items other than "Engine Malfunction" are stored, make sure to perform any troubleshooting for them before clearing Vehicle Control History.

for HEV Model: Click here [INFO](#)

for PHEV Model: Click here [INFO](#)

**HINT:**

If the cable is disconnected from the auxiliary battery terminal, the fuel vapor containment valve cannot close completely and an EVAP SYSTEM DTC will be stored. If the DTC is output, drive the vehicle at a speed of 10 km/h (6 mph) or more and then leave the vehicle for 30 seconds or more. Then perform the Evaporative System Check again.

**PROCEDURE**

<b>1.</b>	<b>GO TO EVAP SYSTEM</b>
-----------	--------------------------

**HINT:**

[Click here](#)

**INFO**

**NEXT**  **END**

