

<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BIWD
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> HYBRID / BATTERY CONTROL: PLUG-IN CHARGE CONTROL SYSTEM (for PHEV Model): P0EFB16; Hybrid/EV Battery Charger "A" Input Voltage Sensor "C" Circuit Low Circuit Voltage Below Threshold; 2023 - 2024 MY Prius Prime [03/2023 - ]		

<b>DTC</b>	<b>P0EFB16</b>	<b>Hybrid/EV Battery Charger "A" Input Voltage Sensor "C" Circuit Low Circuit Voltage Below Threshold</b>
------------	----------------	---

## DESCRIPTION

The charge control ECU built into the electric vehicle charger assembly monitors the input AC voltage by the VAI sensor. If it detects a VAI sensor malfunction, it illuminates the MIL and stores a DTC. If these DTCs are output, replace the electric vehicle charger assembly.

DTC NO.	DETECTION ITEM	DTC DETECTION CONDITION	TROUBLE AREA	MIL	WARNING INDICATE	DTC OUTPUT FROM	PRIORITY	NOTE
P0EFB16	Hybrid/EV Battery Charger "A" Input Voltage Sensor "C" Circuit Low Circuit Voltage Below Threshold	When charging or supplying power, there is a malfunction when there is no VAI signal  (1 trip detection logic)	Electric vehicle charger assembly	Comes on	Master Warning:  Comes on	Plug-in Control	A	SAE Code:  P0EFD

## MONITOR DESCRIPTION

The charge control ECU built into the electric vehicle charger assembly monitors the input AC voltage by the VAI sensor. If it detects a VAI sensor malfunction, it illuminates the MIL and stores a DTC.

## MONITOR STRATEGY

Related DTCs	P0EFD: Battery Charger "A" Input Voltage Sensor "C" Circuit Low
Required sensors/components	Electric vehicle charger assembly
Frequency of operation	Continuous
Duration	TMC's intellectual property
MIL operation	1 charging cycle 1 discharging cycle
Sequence of operation	None

## TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
---	-----------------------------

Other conditions belong to TMC's intellectual property	-
--	---

## TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property	-
-----------------------------	---

## COMPONENT OPERATING RANGE

Electric vehicle charger assembly	DTC P0EFB16 is not detected
-----------------------------------	-----------------------------

## CONFIRMATION DRIVING PATTERN

### HINT:

- After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

[Click here](#) INFO

- When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

[Click here](#) INFO

- Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- Enter the following menus: Powertrain / Hybrid Control / Data List.
- Check that "Hybrid/EV Battery SOC" shows 70% or less.
- Turn the ignition switch off and wait for 2 minutes or more.
- Connect the electric vehicle charger cable assembly, and plug-in charge the vehicle for 30 seconds or more. [\*1]
- Disconnect the electric vehicle charger cable assembly and wait for 10 seconds or more. [\*2]

### HINT:

[\*1] to [\*2]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- Enter the following menus: Powertrain / Plug-in Control / Utility / All Readiness.
- Check the DTC judgment result.

### HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

## PROCEDURE

<b>1.</b>	<b>REPLACE ELECTRIC VEHICLE CHARGER ASSEMBLY</b>
-----------	--

### HINT:

[Click here](#) INFO

**NEXT**  **COMPLETED**

