Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000002BEGN		
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]		
Title: HYBRID / BATTERY CONTROL: PLUG-IN CHARGE CONTROL SYSTEM (for PHEV Model): P0EF728; Hybrid/EV				
Battery Charger Input Voltage Sensor "B" Circuit Range/Performance Signal Bias Level Out of Range / Zero				
Adjustment Failure; 2023 - 2024 MY Prius Prime [03/2023 -]				

DTC		Hybrid/EV Battery Charger Input Voltage Sensor "B" Circuit Range/Performance Signal Bias Level Out of Range / Zero Adjustment Failure
-----	--	--

DESCRIPTION

Internal operation status is monitored by the charge control ECU built into the electric vehicle charger assembly, and when an abnormality is detected, a DTC is stored. If this DTC is output, replace the electric vehicle charger assembly.

DTC	DETECTION ITEM	DTC	TROUBLE	MIL	WARNING	DTC	PRIORITY	NOTE
NO.		DETECTION CONDITION	AREA		INDICATE	OUTPUT FROM		
P0EF728	Hybrid/EV Battery Charger Input Voltage Sensor "B" Circuit Range/Performance Signal Bias Level Out of	When VIN voltage is detected while charging is being stopped (1 trip detection logic)	Electric vehicle charger assembly	Comes	Master Warning: Comes on	Plug-in Control		SAE Code: P0EF8

MONITOR DESCRIPTION

The charge control ECU built into the electric vehicle charger assembly monitors the input AC voltage by the VIN sensor. If it detects a VIN sensor malfunction, it illuminates the MIL and stores a DTC.

MONITOR STRATEGY

Related DTCs	P0EF8: Battery Charger Input Voltage Sensor Circuit Range/Performance			
Required sensors/components	Electric vehicle charger assembly			
Frequency of operation	Continuous			
Duration	TMC's intellectual property			
MIL operation	1 charging cycle 1 discharging cycle			
Sequence of operation	None			

TYPICAL ENABLING CONDITIONS

The monitor will run whenever the following DTCs are not stored	TMC's intellectual property
Other conditions belong to TMC's intellectual property	-

TYPICAL MALFUNCTION THRESHOLDS

TMC's intellectual property -

COMPONENT OPERATING RANGE

Electric vehicle charger assembly DTC P0EF728 is not detected

CONFIRMATION DRIVING PATTERN

HINT:

• After repair has been completed, clear the DTC and then check that the vehicle has returned to normal by performing the following All Readiness check procedure.

Click here NFO

• When clearing the permanent DTCs, refer to the "CLEAR PERMANENT DTC" procedure.

Click here NFO

- 1. Clear the DTCs (even if no DTCs are stored, perform the clear DTC procedure).
- 2. Enter the following menus: Powertrain / Hybrid Control / Data List.
- 3. Check that "Hybrid/EV Battery SOC" shows 70% or less.
- 4. Turn the ignition switch off and wait for 2 minutes or more.
- 5. Connect the electric vehicle charger cable assembly, and plug-in charge the vehicle for 30 seconds or more. [*1]
- 6. Disconnect the electric vehicle charger cable assembly and wait for 10 seconds or more. [*2]

HINT:

[*1] to [*2]: Normal judgment procedure.

The normal judgment procedure is used to complete DTC judgment and also used when clearing permanent DTCs.

- 7. Enter the following menus: Powertrain / Plug-in Control / Utility / All Readiness.
- 8. Check the DTC judgment result.

HINT:

- If the judgment result shows NORMAL, the system is normal.
- If the judgment result shows ABNORMAL, the system has a malfunction.
- If the judgment result shows INCOMPLETE or N/A, perform the normal judgment procedure again.

PROCEDURE

1. REPLACE ELECTRIC VEHICLE CHARGER ASSEMBLY

HINT:

Click here NFO





⊕ TOYOTA