12/15/24, 2:54 PM

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002B77B	
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [03/2023 -]
Title: DOOR / HATCH: CHARGE LID	OPENER SYSTEM: HOW TO	PROCEED WITH TROUBLESHOOTING;	2023 - 2024
MY Prius Prius Prime [03/2023 -]		

HOW TO PROCEED WITH TROUBLESHOOTING

CAUTION / NOTICE / HINT

HINT:

- Use the following procedure to troubleshoot the charge lid opener system.
- *: Use the GTS.

PROCEDURE

VEHICLE BROUGHT TO WORKSHOP

NEXT

1.



2. CUSTOMER PROBLEM ANALYSIS

HINT:

- In troubleshooting, confirm that the problem symptoms have been accurately identified. Preconceptions should be discarded in order to make an accurate judgment. To clearly understand what the problem symptoms are, it is extremely important to ask the customer about the problem and the conditions at the time the malfunction occurred.
- Gather as much information as possible for reference. Past problems that seem unrelated may also help in some cases.
- The following 5 items are important points for problem analysis:

What	Vehicle model, system name	
When	Date, time, occurrence frequency	
Where	Road conditions	
Under what conditions?	Driving conditions, weather conditions	
How did it happen?	Problem symptoms	



_	
3. ∣	PRE-CHECK

7

12/15/24, 2:54 PM DOOR / HATCH: CHARGE LID OPENER SYSTEM: HOW TO PROCEED WITH TROUBLESHOOTING; 2023 - 2024 MY Prius Pri...

(a) Measure the auxiliary battery voltage with the ignition switch off.

Standard voltage:

11 to 14 V

If the voltage is below 11 V, recharge or replace the auxiliary battery before proceeding to the next step.

- (b) Check the fuses and relays.
- (c) Check the connector connections and terminals to make sure that there are no abnormalities such as loose connections, deformation, etc.



4. CHECK COMMUNICATION FUNCTION OF CAN COMMUNICATION SYSTEM*

(a) Using the GTS, check for CAN communication system DTCs.

Click here NFO

RESULT	PROCEED TO	
CAN DTCs are not output	А	
CAN DTCs are output	В	

B GO TO CAN COMMUNICATION SYSTEM



5. PROBLEM SYMPTOMS TABLE

(a) Refer to Problem Symptoms Table.

Click here

RESULT	PROCEED TO
Fault is not listed in Problem Symptoms Table	А
Fault is listed in Problem Symptoms Table	В





6. OVERALL ANALYSIS AND TROUBLESHOOTING*

(a) Data List / Active Test

Click here

(b) Inspection



7. REPAIR OR REPLACE



8. CONFIRMATION TEST





