

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM100000002925H
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: DOOR / HATCH: POWER BACK DOOR CLOSER SWITCH: INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INSPECTION

PROCEDURE

1. INSPECT NO. 1 POWER BACK DOOR CONTROL SWITCH

(a) Check the switch.

(1) Measure the resistance according to the value(s) in the table below.

Standard Resistance:




[Click Location & Routing\(W2\)](#)

[Click Connector\(W2\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
W2-5 (CLS) - W2-2 (E)	Pushed (ON)	Below 1 Ω	Ω
W2-5 (CLS) - W2-2 (E)	Not Pushed (OFF)	10 kΩ or higher	kΩ

If the result is not as specified, replace the No. 1 power back door control switch.



*a	Component without harness connected (No. 1 Power Back Door Control Switch)
----	--

(b) Check the switch illumination.

(1) Apply auxiliary battery voltage to the switch connector and check that the No. 1 power back door control switch illuminates.

OK:



[Click Location & Routing\(W2\)](#)

[Click Connector\(W2\)](#)

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION
Auxiliary battery positive (+) → Terminal W2-6 (ILL+) Auxiliary battery negative (-) → Terminal W2-1 (ILL-)	Always	Switch illumination illuminates

If the result is not as specified, replace the No. 1 power back door control switch.

