


<b>Last Modified:</b> 12-04-2024	6.11:8.1.0	<b>Doc ID:</b> RM10000002BNH3
<b>Model Year Start:</b> 2023	<b>Model:</b> Prius Prime	<b>Prod Date Range:</b> [03/2023 - ]
<b>Title:</b> WINDOW / GLASS: WINDOW DEFOGGER SYSTEM: TERMINALS OF ECU; 2023 - 2024 MY Prius Prius Prime [03/2023 - ]		

## TERMINALS OF ECU

### CHECK POWER DISTRIBUTION BOX ASSEMBLY



(a) Measure the voltage according to the value (s) in the table below.

TESTER CONNECTION	TERMINAL DESCRIPTION	CONDITION	SPECIFIED CONDITION
R17-43 - Body ground	Rear window defogger signal (output)	Rear window defogger switch off	Below 1 V
		Rear window defogger switch on	11 to 14 V

**CHECK AIR CONDITIONING AMPLIFIER ASSEMBLY, AIR CONDITIONING CONTROL ASSEMBLY**

for HEV Model: Click here [INFO](#)

for PHEV Model: Click here [INFO](#)

