

Last Modified: 12-04-2024	6.11:8.1.0	Doc ID: RM10000000293N0
Model Year Start: 2023	Model: Prius Prime	Prod Date Range: [12/2022 -]
Title: SEAT: REAR SEATBACK HEATER: INSPECTION; 2023 - 2024 MY Prius Prius Prime [12/2022 -]		

INSPECTION

PROCEDURE

1. INSPECT REAR NO. 1 SEATBACK HEATER ASSEMBLY LH (for LH Side)


(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R68\)](#)

[Click Connector\(R68\)](#)



*a	Component without harness connected (Rear No. 1 Seatback Heater Assembly LH)
----	--

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
R68-1 - R68-3	Seat heater temperature 20 °C (68 °F)	2.72 to 3.32 Ω	Ω
R68-2 - R68-3	Seat heater temperature 20 °C (68 °F)	1.94 to 2.38 Ω	Ω

If the result is not as specified, replace the rear No. 1 seatback heater assembly LH.

2. INSPECT REAR NO. 1 SEATBACK HEATER ASSEMBLY RH (for RH Side)


(a) Measure the resistance according to the value(s) in the table below.

Standard Resistance:



[Click Location & Routing\(R67\)](#)

[Click Connector\(R67\)](#)



*a	Component without harness connected (Rear No. 1 Seatback Heater Assembly RH)
----	--

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
R67-1 - R67-3	Seat heater temperature 20 °C (68 °F)	2.72 to 3.32 Ω	Ω

If the result is not as specified, replace the rear No. 1 seatback heater assembly RH.

TESTER CONNECTION	CONDITION	SPECIFIED CONDITION	RESULT
R67-2 - R67-3	Seat heater temperature 20 °C (68 °F)	1.94 to 2.38 Ω	Ω

If the result is not as specified, replace the rear No. 1 seatback heater assembly RH.

